

iBaby Labs,Inc.

D-Link_2640T_pfg Port Forwarding

1. Set Static IP address:

Open App, Set Up→ Set Camera IP,Static IP:ON



2. Access router, set Port forwarding

Advanced→Virtual Server:





iBaby Labs,Inc.

ulding Networks for People		A	OSL Router	I. Rule Hank. IDaby
	Home Adv	vanced Tools	Status	He 2. Protocol Select TCP
UPnP /irtual:Server	Rule Name Pretocol Port Start Port Map	TCP P P P	Port End	4. Enter PORT which listed on the iBaby monitor app of the iOS device under Setup>Camere Information>PORT
Enter PORT which listed on the by monitor app of the iOS device der Setup>Camera ormation>PORT		e Apply Cancel		6. Enter PORT which listed on the iBaby monitor app of the iOS devices the iBaby monitor app of the iBaby mon
				under Setup>Camer Information>PORT
5. iB; un	5. Enter PORT which lis iBaby monitor app of the under Setu			7. Click Apply
Int	formation>PORT			
		. 1		